

TIMECLOCK

The arrow highlighted in the yellow circle is the current time indicator in 24hr time. Check that this arrow is at the actual time – e.g. 22 = 10.00pm. This will require re-setting each time the power goes off.



OFF

This photo shows the time clock is totally off, ie the system will only work on solar - no electric boost will kick in.



AUTO

This photo shows the time clock is on and the electric boost will automatically turn on at each green peg and off at each red peg. (Please note: The boost will turn off before the red peg time if the unit reaches temperature and the thermostat switches off.



MANUAL

This photo shows the time clock is on manual and the electric boost will work continuously in the 24/7 mode and is only controlled by the thermostat, ie the boost will turn on when the unit drops below temperature and off when the unit reaches temperature ó this mode continues switching on and off 24 hours a day.